



Example of breakaway tabs on a PCB panel.

After board is depaneled, tab jaggies can be taken down with fine sandpaper

Inset drawing is rotated 90 degrees.