

- OPEN TRUNK
- FROM INSIDE, CLOSE & LOCK ALL DOORS
- INSERT & REMOVE KEY > 6 TIMES IN 10 SECS
- UNLOCK/LOCK DRIVER DOOR MANUALLY
- PRESS REMOTE LOCK BUTTON
- UNLOCK/LOCK DRIVER DOOR MANUALLY
- PRESS 2ND REMOTE LOCK BUTTON
- OPEN DRIVER DOOR